



## yupo octopus

---

### Converting Tips for YUPO® "Octopus"

#### Sheet Offset Printing

Printing Pressure:	Set the sheet thickness on the press at 250 microns.
Ink:	Use foil (film) ink or synthetic paper ink.
Spray powder:	Set spray powder 50% more than amount used on coated paper.
Fanning/Stacking:	Do not over bend when fanning and stacking, air may go into between release liner and Yupo®.
Winter season:	Bring YUPO® Octopus into press room at least one day before printing to prevent from curling by shrinkage of release liner.

#### Full Die Cut

- Cut from printing side.
- Corners should be round to prevent from tearing.

#### Half Die Cut

- Cut from printing side.
- Not recommended for back side (release liner) slitting because release liner is thin.
- Not recommended for complicated shapes. Corners should be round to prevent tearing.
- Please pay attention to the height of rule die and use spacer if needed to cut evenly.